

About This Manual.

Return of products

Please contact our Service Team before returning a defective device. Ship the cleaned device to the address you have been given. If the device has been in contact with process fluids, it must be decontaminated/disinfected before shipment. In that case, please attach a corresponding certificate, for the health and safety of our service personnel.


Disposal

Please observe the applicable local or national regulations concerning the disposal of "waste electrical and electronic equipment".

About this manual:

This manual is intended as a reference guide to your device – You don't have to read the book from front to back.

Take a look at the **Table of Contents** or the **Index** to find the function you are interested in. Each topic is explained on a double-page spread with step-by-step instructions on how to configure the desired function. Clearly legible page numbers and headlines help you to quickly find the information:



Right page: Which settings are provided for this function

Safety Instructions

In official EU languages and others

Quickstart Guides

Installation and first steps:

- Operation
- Menu structure
- Calibration
- · Error messages and recommended actions

Specific Test Report

Electronic Documentation

Manuals + Software

Ex Devices:

Control Drawings

EU Declarations of Conformity

Up-to date documentation available on our website:



www.knick.de

Contents

Documents Supplied	3
Introduction	
Intended Use	7
Safety Information	10
Overview of Stratos Pro A2 OXY	11
Assembly	12
Package Contents	12
Mounting Plan, Dimensions	
Pipe Mounting, Protective Hood	
Panel Mounting	
Installation	
Installation Instructions	
Rating Plates / Terminal Assignments	
Wiring of Stratos Pro A2 OXY	1/
Wiring Examples	
User Interface, Keypad	
Display	
Signal Colors (Display Backlighting)	
Measuring Mode	
Selecting the Mode / Entering Values	
Color-Coded User Interface	26
Operating Modes	
Menu Structure of Modes and Functions	
HOLD Mode	
Alarm	
Alarm and HOLD Messages	
Configuration	
Menu Structure of Configuration	
Manual Switchover of Parameter Sets A/B	
Configuration (Template for Copy)	
SensorSensor Verification (TAG, GROUP)	
	52

Contents

Current Output 1	54
Current Output 2	62
Correction	64
CONTROL Input	
Alarm Settings	
Time and Date	
Measuring Points (TAG/GROUP)	74
Digital Sensors	76
Memosens Sensors:	
Calibration and Maintenance in the Lab	
Memosens Sensors: Configuring the Device	
Replacing a Sensor	78
Calibration	
Selecting a Calibration Mode	81
Zero Calibration	
Product Calibration	
Slope Calibration (Medium: Water)	
Slope Calibration (Medium: Air)	
Temp Probe Adjustment	
Measurement	89
Diagnostics	90
Service	95
Operating States	98
A2X: Supply Units and Connection	99
Product Line and Accessories	100
Specifications	101
Error Handling	108
Error Messages	109
Sensoface	112
FDA 21 CFR Part 11	115
Electronic Signature – Passcodes	115
Audit Trail	115

Contents

Index	
Trademarks	
Passcodes	

Intended Use

Stratos Pro A2... OXY is a 2-wire device for dissolved oxygen and temperature measurement in biotechnology, pharmaceutical industry, as well as in the field of industry, environment, food processing and sewage treatment. Optionally, it can be used for measuring oxygen traces.

Enclosure and mounting possibilities

- The sturdy molded enclosure is rated IP 67/NEMA 4X for outdoor use. It is made of glass-reinforced PBT / PC and measures 148 mm x 148 mm x 117 mm (H x W x D). It is provided with knockouts to allow:
- wall mounting (with sealing plugs to seal the enclosure), see page 13
- post/pipe mounting (Ø 40 ... 60 mm, □ 30 ... 45 mm) see page 14
- panel mounting (138 mm x 138 mm cutout to DIN 43700), see page 15

Weather protector (accessory)

The weather protector, which is available as accessory, provides additional protection against direct weather exposure and mechanical damage, see page 14.

Connection of sensors, cable glands

For connecting the cables, the enclosure provides

- 3 knockouts for cable glands M20x1.5
- 2 knockouts for NPT 1/2" or rigid metallic conduit

For quasi-stationary installations with Memosens sensors, we recommend using the M12 device socket (accessory ZU 0822) instead of a cable gland – it allows simple replacement of the sensor cable without opening the device.

Sensors

The device has been designed for amperometric sensors, e.g. Knick SE 704 / SE 705 / SE 706 / SE 707 and for ISM sensors. (It can be easily retrofitted for Memosens sensors.)

Introduction

Display

Plain-text messages in a large, backlit LC display allow intuitive operation. You can specify which values are to be displayed in standard measuring mode ("Main Display", see page 25).

Color-coded user interface

The colored display backlighting signals different operating states (e.g. alarm: red, HOLD mode: orange, see page 26).

Diagnostics functions

"Sensocheck" and "Sensoface" monitor the sensor and provide clear information about its status, see page 112.

Data logger

The internal logbook (TAN SW-A002) can handle up to 100 entries – up to 200 with AuditTrail (TAN SW-A003), see page 93.

2 parameter sets A/B

The device provides two parameter sets which can be switched manually or via a control input for different process adaptations or different process conditions.

For overview of parameter sets (table for copy), see page 42.


Password protection

Password protection (passcodes) for granting access rights during operation can be configured, see page 97.

Correction

Here, you can adapt the device to the process conditions by means of salinity and pressure correction, either manually or via an external current input (optional, released by TAN), see page 64.

Control inputs



l input

The analog (0) 4 ... 20 mA current input can be used for external pressure compensation (TAN required). See page 60.

HOLD

(floating digital control input) The HOLD input can be used for external activation of the HOLD mode, see page 29.

CONTROL

(floating digital control input) The CONTROL input can be used either for parameter set selection (A/B) or for flow monitoring, see page 62.

Signal outputs

The device provides two current outputs (for transmission of measured value and temperature, for example).

Options

Additional functions can be activated by entering a TAN (page 97).

Safety Information

Safety Information

Be sure to read and observe the following instructions!

The device has been manufactured using state of the art technology and it complies with applicable safety regulations.

When operating the device, certain conditions may nevertheless lead to danger for the operator or damage to the device.



When using the device in a hazardous location, observe the specifications of the Control Drawing.

Commissioning must only be performed by trained personnel authorized by the operating company! Whenever it is likely that protection has been impaired, the device shall be made inoperative and secured against unintended operation.

The protection is likely to be impaired if, for example:


- the device shows visible damage
- · the device fails to perform the intended measurements
- after prolonged storage at temperatures below -30 °C / -22 °F or above +70 °C / +158 °F
- after severe transport stresses

Before recommissioning the device, a professional routine test must be performed. This test must be carried out at the manufacturer's factory.

Note:

Before commissioning you must prove that the device may be connected with other equipment.

Overview of Stratos Pro A2... OXY



Assembly

Package Contents

Check the shipment for transport damage and completeness! **The package should contain:**

- Front unit, rear unit, bag containing small parts
- Specific test report
- Documentation (cf p. 3)






Fig.: Assembling the enclosure


- 1) Jumper (3 x)
- 2) Washer (1 x), for conduit mounting: Place washer between enclosure and nut
- 3) Cable tie (3 x)
- 4) Hinge pin (1 x), insertable from either side
- 5) Enclosure screw (4 x)

- 6) Sealing insert (1 x)
- 7) Rubber reducer (1 x)
- 8) Cable gland (3 x)
- 9) Filler plug (3 x)
- 10) Hexagon nut (5 x)
- 11) Sealing plug (2 x), for sealing in case of wall mounting

Mounting Plan, Dimensions








- 1) Cable gland (3 x)
- 2) Knockouts for cable gland or 1/2" conduit,
 - 21.5 mm dia. (2 knockouts)
- Conduit couplings not included!
- 3) Knockout for pipe mounting (4 x)
- 4) Knockout for wall mounting (2 x)

Fig.: Mounting plan (All dimensions in mm!)

Pipe Mounting, Protective Hood



- 1) Hose clamp with worm gear drive to DIN 3017 (2 x)
- 2) Pipe-mount plate (1 x)
- 3) For vertical or horizontal posts or pipes
- 4) Self-tapping screw (4 x)

Fig.: Pipe-mount kit, accessory ZU 0274 (All dimensions in mm!)





Fig.: Protective hood for wall and pipe mounting, accessory ZU 0737 (All dimensions in mm!)

Panel Mounting



- 1) Circumferential sealing (1 x)
- 2) Screws (4 x)
- 3) Position of control panel
- 4) Span piece (4 x)
- 5) Threaded sleeve (4 x)

Cutout 138 x 138 mm (DIN 43700)

Fig.: Panel-mount kit, accessory ZU 0738 (All dimensions in mm!)

Installation Instructions

- Installation of the device must be carried out by trained experts in accordance with this user manual and as per applicable local and national codes.
- Be sure to observe the technical specifications and input ratings during installation!
- Be sure not to notch the conductor when stripping the insulation!
- The supplied current must be galvanically isolated. If not, connect an isolator module.
- All parameters must be set by a system administrator prior to commissioning!

Terminals:

suitable for single wires / flexible leads up to 2.5 mm² (AWG 14)

Rating Plates / Terminal Assignments





Fig.: Terminal assignments of Stratos Pro A2...



Fig.: Stratos Pro A2...N rating plate at outside bottom of front

Wiring of Stratos Pro A2... OXY




In addition: 2 HART pins (between terminal row 1 and 2)

Fig.: Terminals, device opened, back of front unit

Wiring Examples


Example 1:

Measuring task: Sensors (example): Cable (example): Oxygen STANDARD "10" (e.g. SE 706, InPro 6800) VP 6 ZU 0313 (Knick)



Example 2:

Measuring task: Sensors (example): Cable (example): Oxygen TRACES (TAN required) "01" (e.g. SE 707, InPro 6900) VP6 ZU 0313 (Knick)





Wiring Examples

Example 3:

Measuring task: Cable (example):


Oxygen SUBTRACES (TAN required) Sensors (example): "001" (e.g. SE 708, InPro 6950) VP6 ZU 0313 (Knick)





Кеу	Function
meas	 Return to last menu level Directly to measuring mode (press > 2 s) Measuring mode: other display
info	Retrieve informationShow error messages
enter	 Configuration: Confirm entries, next configuration step Calibration: Continue program flow
menu	Measuring mode: Call menu
Arrow keys up / down	Menu: Increase/decrease a numeralMenu: Selection
Arrow keys left / right	 Previous/next menu group Number entry: Move between digits

Display




Signal Colors (Display Backlighting)

Red	Alarm (in case of fault: display values blink)
Red blinking	Input error: illegal value or wrong passcode
Orange	HOLD mode (Calibration, Configuration, Service)
Turquoise	Diagnostics
Green	Info
Purple	Sensoface message

Measuring Mode

After the operating voltage has been connected, the analyzer automatically goes to "Measuring" mode. To call the measuring mode from another operating mode (e.g. Diagnostics, Service): Hold **meas** key depressed (> 2 s).



Depending on the configuration, one of the following displays can be set as standard display for the measuring mode (see page 25):

- Measured value, time and temperature (default setting)
- Measured value and selection of parameter set A/B or flow Measured value and tag number ("TAG")
- Time and date

Note: By pressing the **meas** key in measuring mode you can view the displays for approx. 60 sec.




The device must be configured for the respective measurement task!

Selecting the Mode / Entering Values


To select the operating mode:

- 1) Hold meas key depressed (> 2 s) (directly to measuring mode)
- 2) Press menu key: the selection menu appears
- 3) Select operating mode using left / right arrow key
- 4) Press enter to confirm the selected mode




To enter a value:

- 5) Select numeral: left / right arrow key
- 6) Change numeral: up / down arrow key
- 7) Confirm entry by pressing enter



Display in Measuring Mode




Color-Coded User Interface

The color-coded user interface guarantees increased operating safety. Operating modes are clearly signaled.

The normal measuring mode is white. Information text appears on a green screen and the diagnostic menu appears on turquoise.

The orange HOLD mode (e.g. during calibration) is quickly visible as is the magenta screen which indicates asset management messages for predictive diagnostics – such as maintenance request, pre-alarm and sensor wear.

The alarm status has a particularly noticeable red display color and is also signaled by flashing display values. Invalid inputs or false passcodes cause the entire display to blink red so that operating errors are noticeably reduced.



Diagnostics

Display of calibration data, display of sensor data, performing a device self-test, viewing the logbook entries, display of hardware/software versions of the individual components. The logbook can store 100 events (00...99). They can be displayed directly on the device. The logbook can be extended to 200 entries using a TAN (Option).

HOLD

Manual activation of HOLD mode, e.g. for replacing a digital sensor. The signal outputs adopt a defined state.

Calibration

Every sensor has typical characteristic values, which change in the course of the operating time. Calibration is required to supply a correct measured value. The device checks which value the sensor delivers when measuring in a known solution. When there is a deviation, the device can be "adjusted". In that case, the device displays the "actual" value and internally corrects the measurement error of the sensor. Calibration must be repeated at regular intervals. The time between the calibration cycles depends on the load on the sensor. During calibration the device is in HOLD mode.

During calibration the device remains in the HOLD mode until it is stopped by the operator.


Configuration

The analyzer must be configured for the respective measurement task. In the "Configuration" mode you select the connected sensor, the measuring range to be transmitted, and the conditions for warning and alarm messages. During configuration the device is in HOLD mode. **Configuration mode is automatically exited 20 minutes after the last keystroke. The device returns to measuring mode.**

Service

Maintenance functions (monitor, current source), passcode assignment, reset to factory settings, enabling of options (TAN).

Menu Structure of Modes and Functions




The HOLD mode is a safety state during configuration and calibration. Output current is frozen (LAST) or set to a fixed value (FIX). The HOLD mode is indicated by orange display backlighting.

HOLD mode, display icon:



- **LAST:** The output current is frozen at its last value. Recommended for short configuration procedures. The process should not change decisively during configuration. Changes are not noticed with this setting!
- **FIX:** The output current is set to a value that is noticeably different from the process value to signal the control system that the device is being worked at.

Output signal during HOLD:



Terminating the HOLD mode

The HOLD mode is ended by switching to measuring mode (hold **meas** key depressed). The display reads "Good Bye", after that, the HOLD mode is exited.


When the calibration mode is exited, a confirmation prompt ensures that the installation is ready for operation (e.g.: sensor reinstalled, located in process).



Alarm

External activation of HOLD

The HOLD mode can be activated from outside by sending a signal to the HOLD input (e.g. from the process control system).



Manual activation of HOLD

The HOLD mode can be activated manually from the HOLD menu. This allows checking or replacing a sensor, for example, without provoking unintended reactions at the outputs.

Press meas key to return to selection menu.

Alarm

When an error has occurred, **Err xx** is displayed immediately. Only after expiry of a user-defined delay time will the alarm be registered and entered in the logbook.

During an alarm the display blinks, the display backlighting turns red.

Error messages can also be signaled by a 22 mA output current (see Configuration).

2 sec after the failure event is corrected, the alarm status will be deleted.

Message	Released by	Cause
Alarm	Sensocheck	Polarization / Cable
(22 mA)	Error Messages	Flow (CONTROL input)
HOLD	HOLD	HOLD via menu or input
(Last/Fix)	CONF	Configuration
	CAL	Calibration
	SERVICE	Service

Generating a message via the CONTROL input (min. flow / max. flow)

The CONTROL input can be used for parameter set selection or for flow measurement (pulse principle), depending on its assignment in the "Configuration" menu.


When preset to flow measurement

CONF/CNTR_IN/CONTROL = FLOW

an alarm can be generated when the measured flow exceeds a specified range:

CONF/ALA/FLOW CNTR = ON

CONF/ALA/FLOW min (specify value, default: 5 liters/h) **CONF/ALA/FLOW max** (specify value, default: 25 liters/h)



Menu Structure of Configuration

The device provides 2 parameter sets "A" and "B". By switching between the parameter sets you can adapt the device to different measurement situations, for example. Parameter set "B" only permits setting of process-related parameters.

The configuration steps are assigned to different menu groups.

With the left/right arrow keys you can jump between the individual menu groups. Each menu group contains menu items for setting the parameters.

Pressing enter opens a menu item. Use the arrow keys to edit a value.

Press **enter** to confirm/save the settings.

Return to measurement: Hold **meas** key depressed (> 2 s).

Select menu group	Menu group	Code	Display	Select menu item
	Sensor selection	SNS:		enter
		Menu ite		Senter
			:	🕈 enter
		Menu ite		`
• (Current output 1	OT1:) enter
	Current output 2	OT2:		
	Compensation	COR:		
•	Control input (parameter set or flow measurement)	IN:		
۰ ۱	Alarm mode	ALA:		◄) •
	Setting the clock	CLK:		✓ う •
×	Tag number	TAG:		/


Parameter set A/B: configurable menu groups

The device provides 2 parameter sets "A" and "B". By switching between the parameter sets you can adapt the device to different measurement situations, for example. Parameter set "B" only permits setting of process-related parameters.

Menu group	Parameter set A	Parameter set B
SENSOR	Sensor selection	
OUT1	Current output 1	Current output 1
OUT2	Current output 2	Current output 2
CORRECTION	Compensation	Compensation
CNTR_IN	Control input	
ALARM	Alarm mode	Alarm mode
PARSET	Parameter set selection	
CLOCK	Setting the clock	
TAG	TAG of measuring point	
GROUP	GROUP of measuring points	

External switchover of parameter sets A/B

You can switch between parameter sets A and B by applying a signal to the CONTROL input (parameter setting: CNTR-IN – PARSET).



Manual Switchover of Parameter Sets A/B

Display	Action	Remark
	To switch between parameter sets: Press meas .	Manual selection of parameter sets must have been preset in CONFIG mode. Default setting is a fixed parameter set A. Wrong settings change the measurement properties!
	PARSET blinks in the lower line. Select parameter set using ◀ and ▸ keys	
	Select PARSET A / PARSET B	
	Press enter to confirm. Cancel by pressing meas .	

Configu	ration			Choices	Default
Sensor (SENSOR)					
SNS:	(Select text lin	ie)		STANDARD 10 Typ TRACES 01 Typ SUBTRACES 001 T. (requires "Traces" Option) ISM-DIGITAL MEMOSENS	STANDARD 10 Typ
	MEAS MODE			dO % dO mg/l dO ppm GAS %	dO %
	U-POL			-4001000 mV (00001000 mV for traces)	-675 mV
	MEMBR. COM	MEMBR. COMP.			01.00
	RTD TYPE			22 NTC 30 NTC	22 NTC
	TEMP UNIT			°C / °F	°C
	CAL MODE			CAL AIR CAL WTR	CAL AIR
	CALTIMER			ON/OFF	OFF
	ON	CAL-0	CYCLE	09999 h	0168 h
	Memosens*	CIP COUNT		ON/OFF	OFF
		ON	CIP CYCLES	09999 CYC	0025 CYC
		SIP C	OUNT	ON/OFF	OFF
		ON	SIP CYCLES	09999 CYC	0025 CYC
		AUTOCLAVE		ON / OFF	OFF
		CHECK TAG/ GROUP		ON / OFF	OFF

* for digital sensors and Memosens only

Conf	figuratior	1	Choices	Default		
Output 1 (OUT1, no trace measurement)						
OT1:	CHANNEL		OXY/TMP	OXY		
	OXY dO %	BEGIN 4mA	000.0600.0 %	000.0 %		
		END 20 mA	0.000600.0 %	600.0 %		
	OXY dO	BEGIN 4mA	00.0099.99 mg/l			
	mg/l	END 20 mA	00.0099.99 mg/l			
	OXY dO	BEGIN 4mA	00.0099.99 ppm			
	ppm	END 20 mA	00.0099.99 ppm			
	OXY GAS %	BEGIN 4mA	00.0099.99 %			
		END 20 mA	00.0099.99 %			
	TMP °C	BEGIN 4mA	–20150 °C			
		END 20 mA	–20150 °C			
	TMP °F	BEGIN 4mA	–4302 °F			
		END 20 mA	–4302 °F			
	FILTERTIME		0120 SEC	0000 SEC		
	FAIL 22mA		ON/OFF	OFF		
	FACE 22mA		ON/OFF	OFF		
	HOLD MOD	E	LAST/FIX	LAST		
	FIX	HOLD-FIX	422 mA	021.0 mA		

Conf	figuratio	n	Choices	Default
-	ut 1 (OUT1			
		nent, sensor type	01, TAN required	0)/1/
OT1:	CHANNEL		OXY/TMP	OXY
	OXY dO %	BEGIN 4mA	000.0150.0 %	000.0 %
		END 20 mA	000.0150.0 %	150.0 %
	OXY dO	BEGIN 4mA	0000 μg/l20.00 mg/l	
	mg/l	END 20 mA	0000 μg/l20.00 mg/l	
	OXY dO	BEGIN 4mA	0000 ppb20.00 ppm	
	ppm	END 20 mA	0000 ppb20.00 ppm	
	OXY GAS %	BEGIN 4mA	0000 ppm 50.00 %	
		END 20 mA	0000 ppm 50.00 %	
	TMP °C	BEGIN 4mA	–20150 °C	
		END 20 mA	–20150 °C	
	TMP °F	BEGIN 4mA	–4302 °F	
		END 20 mA	–4302 °F	
	FILTERTIME		0120 SEC	0000 SEC
	FAIL 22mA		ON/OFF	OFF
	FACE 22mA		ON/OFF	OFF
	HOLD MOD	Ε	LAST/FIX	LAST
	FIX	HOLD-FIX	422 mA	021.0 mA

Con	figuration	1	Choices	Default
Outp	ut 1 (OUT1)		
Trace	e measurer	nent, sensor type	e 001, TAN required	
OT1:	CHANNEL		OXY/TMP	OXY
	OXY dO %	BEGIN 4mA	000.0150.0 %	000.0 %
		END 20 mA	000.0150.0 %	150.0 %
	OXY dO	BEGIN 4mA	000.0 μg/l 20.00 mg/l	
	mg/l	END 20 mA	000.0 μg/l 20.00 mg/l	
	OXY dO	BEGIN 4mA	000.0 ppb 20.00 ppm	
	ppm	END 20 mA	000.0 ppb 20.00 ppm	
	OXY GAS %	BEGIN 4mA	0000 ppb50 %	
		END 20 mA	0000 ppb50 %	
	TMP °C	BEGIN 4mA	−20150 °C	
		END 20 mA	−20150 °C	
	TMP °F	BEGIN 4mA	–4302 °F	
		END 20 mA	–4302 °F	
	FILTERTIME		0120 SEC	0000 SEC
	FAIL 22mA		ON/OFF	OFF
	FACE 22mA		ON/OFF	OFF
	HOLD MOD	E	LAST/FIX	LAST
	FIX	HOLD-FIX	422 mA	021.0 mA

			_		
Con	figuratio	n		Choices	Default
Output 2 (OUT2)					
OT2:	CHANNEL			OXY/TMP	ТМР
	other step	os like out	put 1		
Salin	ity or pres	sure co	mpensatio	n (CORRECTION)
COR:	SALINITY		00.0045.00 ppt	00.00 ppt	
	PRESSURE U	JNIT		BAR/KPA/PSI	BAR
	PRESSURE			MAN/EXT *)	
	MAN	BAR		0.0009.999 BAR	1.013 BAR
		KPA		000.0999.9 KPA	
		PSI		000.0145.0 PSI	
	EXT	l-Inpu	t	OFF/4(0)20 mA	420 mA
		BAR	BEGIN 4mA (0 mA)	0.0009.999 BAR	0.000 BAR
			END 20 mA	0.0009.999 BAR	9.999 BAR
		KPA	BEGIN 4mA (0 mA)	000.0999.9 KPA	
			END 20 mA	000.0999.9 KPA	
		PSI	BEGIN 4mA (0 mA)	000.0145.0 PSI	
			END 20 mA	000.0145.0 PSI	
Cont	rol input (N)		
IN:	CONTROL			PARSET, FLOW	PARSET
	FLOW	FLOW AI	DJUST	12000 pulses/liter	0 20000 pulses/liter
Alarm (ALARM)					
ALA:	DELAYTIME		0600 SEC	0010 SEC	
	SENSOCHE			ON/OFF	OFF
	FLOW CNTF			ON/OFF	OFF
	ON	FLOW M		005.0 L/h	0 99.9 L/h
		FLOW M	AX ^{**)}	025.0 L/h	0 99.9 L/h

*) only displayed if enabled

**) Hysteresis fixed at 5% of threshold value

Config	guration		Choices	Default
Parame	eter set (PAF	RSET)		
PAR:	Select fixed parameter set (A) or switch between A/B via control input or manually in measuring mode		PARSET FIX A/ CNTR INPUT / MANUAL	PARSET FIX A (fixed parameter set A)
Real-ti	me <mark>clock</mark> (Cl	-OCK)		
CLK:	FORMAT		24 h / 12 h	
	24 h	TIME hh/mm	0023:0059	
	12 h	TIME hh/mm	0011:0059 AM/PM:	
	DAY/MONTH		0131/0112	
	YEAR		20002099	
Measuring points (TAG / GROUP)				
TAG:	(Input in text line)		AZ, 09, - + < > ? / @	
GROUP:	(Input in text	line)	000099999	

Sensor Verification (TAG, GROUP)

When Memosens sensors are calibrated in the lab, it is often useful and sometimes even mandatory that these sensors will be operated again at the same measuring points or at a defined group of measuring points. To ensure this, you can save the respective measuring point (TAG) or group of measuring points (GROUP) in the sensor. TAG and GROUP can be specified by the calibration tool or automatically entered by the transmitter. When connecting an MS sensor to the transmitter, it can be checked if the sensor contains the correct TAG or belongs to the correct GROUP. If not, a message will be generated, Sensoface gets "sad", and the display backlighting turns purple (magenta). The "sad" Sensoface icon can also be signaled by a 22 mA error current. Sensor verification can be switched on in the Configuration in two steps as TAG and GROUP if required.

When no measuring point or group of measuring points is saved in the sensor, e.g., when using a new sensor, Stratos enters its own TAG and GROUP. When sensor verification is switched off, Stratos always enters its own measuring point and group. A possibly existing TAG/GROUP will be overwritten.

Two complete parameter sets are stored in the EEPROM. As delivered, the two sets are identical but can be edited.

Note:

Fill in your configuration data on the following pages or use them as original for copy.

Configuration (Template for Copy)

Parameter	Parameter set A	Parameter set B
SNS: Sensor type		* ⁾
SNS: Measuring mode		* ⁾
SNS: Voltage polarization		* ⁾
SNS: MEMBR. COMP.		*)
SNS: RTD type		* ⁾
SNS: Temperature unit		* ⁾
SNS: Calibration mode		* ⁾
SNS: Calibration timer		* ⁾
SNS: Calibration cycle		* ⁾
SNS: CIP counter		*)
SNS: SIP counter		*)
SNS: Autoclaving counter		*)
SNS: CHECK TAG		* ⁾
SNS: CHECK GROUP		*)
OT1: Process variable		
OT1: Current start		
OT1: Current end		
OT1: Filter time		
OT1: FAIL 22 mA (error messages)		
OT1: FACE 22 mA (Sensoface messages)		
OT1: HOLD mode		
OT1: HOLD FIX current		
OT2: Process variable		
OT2: Current start		
OT2: Current end		
OT2: Filter time		
OT2: FAIL 22 mA		
(error messages)		
OT2: FACE 22 mA (Sensoface messages)		
(Jensolace messages)		


Configuration (Template for Copy)

Parameter	Parameter set A	Parameter set B
OT2: HOLD mode		
OT2: HOLD FIX current		
COR: Salinity (ppt)		
COR: Pressure unit (BAR, KPA, PSI)		
COR: Pressure (MAN/EXT)		
COR: Ext. current input (Option)		
IN: Parameter set A/B or flow		
IN: (Flow meter) Adjusting pulses/liter		
ALA: Delay		
ALA: Sensocheck on/off		
ALA: Flow control FLOW CNTR on/off		
ALA: Minimum flow (hysteresis fixed at 5 %)		
ALA: Maximum flow (hysteresis fixed at 5 %)		
PAR: Parameter set selection		* ⁾
CLK: Time format		* ⁾
CLK: Time hh/mm		* ⁾
CLK: Day/month		* ⁾
CLK: Year		*)
TAG: Measuring point (tag number)		
GROUP: Group of measuring points		

*) These parameters cannot be adjusted in parameter set B, the values are the same as in parameter set A.

Sensor


Select: Measuring mode, sensor type analog/digital, polarization voltage, membrane compensation, temp probe type



- 1) Press menu key.
- 2) Select **CONF** using **↓** keys, press **enter**.
- 3) Select parameter set using ◀ ▶, press enter.
- 4) Select **SENSOR** menu using **∢ ▶** keys, press enter.
- 5) All items of this menu group are indicated by the "SNS:" code. Press enter to select menu,

edit using arrow keys (see next page). Confirm (and proceed) by pressing **enter**.


6) Exit: Press meas key until the [meas] mode indicator is displayed.



5		Configuration
Menu item	Action	Choices
Select sensor type analog/digital	Select sensor type using ▲ ▼ keys.	STANDARD 10 Typ TRACES 01 Typ SUBTRACES 001 Typ ISM
SNS: STANJARJ	Press enter to confirm.	MEMOSENS
Select measuring mode	Select measuring mode using ▲ ▼ keys. DO: Measurement in liquids GAS:	dO %, dO mg/l dO ppm GAS %
	Measurement in gases Press enter to confirm.	
Polarization voltage (not for Memosens)	To be entered separately for measurement/calibra- tion. For measuring in the trace range: U-POL MEAS = -500 mV Enter V _{pol} using $\checkmark \checkmark \checkmark$	-675 mV -400–1000 mV (0000–1000 mV for trace measurement)
	keys. Press enter to confirm.	
Membrane compensation	 (not for ISM/Memosens) Enter membrane compensation using ▲ ▼ ↓ ▶ keys. 	01.00 00.5005.00
SNS: MEMBR. COMP	Press enter to confirm.	
Type of temp probe	(not for ISM/Memosens) Select type of tempera- ture probe using ▲ ▼	22 NTC 30 NTC
SNS: RTD TYPE	keys. Press enter to confirm.	

E

Sensor Select: Temperature unit, medium: water/air, calibration timer



- 1) Press menu key.
- 2) Select **CONF** using **∢ ▶** keys, press **enter**.
- 3) Select parameter set using ◀ ▶, press **enter**.
- Select SENSOR menu using < → keys, press enter.
- 5) All items of this menu group are indicated by the "SNS:" code.
 Press enter to select menu, edit using arrow keys (see next page).
 Confirm (and proceed) by pressing enter.
- 6) Exit: Press **meas** key until the [meas] mode indicator is displayed.

	5	
	Select sensor type	enter
	Select measuring mode	
	Polarization voltage	ر ا
	Membrane compensation	
	Type of temp probe	
1	Temperature unit	
	Calibration medium water/air	
	Calibration timer	
	CIP/SIP cycles	
	Autoclaving counter	
	CHECK TAG	
	CHECK GROUP	

3		comgaration
Menu item	Action	Choices
Temperature unit	Select temperature unit using \blacktriangle \checkmark keys.	° C °F
SNS: TEMP UN!T	Press enter to confirm.	
Medium: air/water	Select calibration medium using ▲	CAL_AIR CAL WTR
SNS: CALMOJE	AIR: Air as cal medium WTR: Air-saturated water as cal medium	
	Press enter to confirm.	
Calibration timer	Select/deselect calibration timer using ▲ ▼ keys.	OFF ON
	Press enter to confirm.	
(ON: Calibration cycle)	Enter calibration cycle in hours using $\checkmark \checkmark \checkmark \checkmark$ keys.	09999 h 0168 h
	Press enter to confirm.	


Note for the calibration timer:

5

When Sensocheck has been activated in the Configuration – Alarm menu, the expiration of the calibration interval is indicated by Sensoface (beaker icon and smiley).

The calibration timer settings apply to both parameter sets A and B. The time remaining until the next due calibration can be seen in the diagnostics menu (see "Diagnostics").


Sensor Adjust: CIP cleaning cycles, SIP sterilization cycles



- 1) Press menu key.
- Select CONF using < ► keys, press enter.
- 3) Select parameter set using ◀ ▶, press **enter**.
- Select SENSOR menu using < ► keys, press enter.
- All items of this menu group are indicated by the "SNS:" code.
 Press enter to select menu,

edit with arrow keys (see next page). Confirm (and proceed) with **enter**.

6) Exit: Press **meas** key until the [meas] mode indicator is displayed.



		configuration
Menu item	Action	Choices
CIP counter	Adjust CIP counter using ▲ ▼ keys: OFF: No counter ON: Fixed cleaning cycle (adjust in the next step) Press enter to confirm.	OFF/ON
CIP cycles	 Only with CIP COUNT ON: Enter max. number of cleaning cycles using ▲ ▼ ▲ ▶ keys. Press enter to confirm. 	09999 CYC (0000 CYC)
SIP counter	Adjust SIP counter using ▲ ▼ keys: OFF: No counter ON: Max. sterilization cycles (adjust as for CIP counter) Press enter to confirm.	OFF/ON

Logging the cleaning and sterilization cycles with connected sensor helps measuring the load on the sensor.

Suitable for biochemical applications (process temp approx.


0 ... +50 °C / +32 ... +122 °F, CIP temp > +55 °C / +131 °F, SIP temp > +115 °C / +239 °F).

Note:

A CIP or SIP cycle is only entered into the logbook 2 hours after the start to ensure that the cycle is complete.

With Memosens, an entry is also made in the sensor.


Sensor Adjust: Autoclaving counter



- 1) Press menu key.
- Select CONF using < ► keys, press enter.
- 3) Select parameter set using ↓ ▶ keys, press **enter**.
- Select SENSOR menu using < ▶ keys, press enter.
- All items of this menu group are indicated by the "SNS:" code.
 Press enter to select menu.

edit using arrow keys (see next page). Confirm (and proceed) by pressing **enter**.

6) Exit: Press **meas** key until the [meas] mode indicator is displayed.



Autoclaving Counter


After reaching a specified limit value the autoclaving counter generates a Sensoface message. As soon as the counter has reached the specified value, Sensoface is getting "sad". Pressing the info key shows the text "AUTOCLAVE CYCLES OVERRUN" which reminds you that the maximum number of autoclaving cycles has been reached. After each autoclaving process, you must manually increment the autoclaving counter in the SENSOR service menu on the transmitter. The transmitter displays "INCREMENT AUTOCLAVE CYCLE" as confirmation. You can configure the current outputs so that a Sensoface message generates a 22-mA error signal, see page 59.

Menu item	Action	Choices
Autoclaving counter	Select using ▲ ▼ keys: ON:	OFF/ON
	The cycles are specified manually (0 9999)	
SNS: AUTOCLAVE	Press enter to confirm.	

With the autoclaving counter switched on, you must increment the count after each autoclaving process in the SERVICE menu SENSOR/ AUTOCLAVE :

Incrementing the autoclaving counter (SERVICE menu)	After having completed an autoclaving process, open the SERVICE menu SENSOR / AUTOCLAVE to	NO / YES
ZÝ ×E S AUTOELAVE ÷1	increment the autoclav- ing count. To do so, select " YES " and confirm by pressing enter .	


Memosens Sensor Sensor Verification (TAG, GROUP)



- 1) Press menu key.
- Select CONF using < → , press enter.
- 3) Select parameter set using → keys, press **enter**.
- Select SENSOR menu using < ► keys, press enter.
- All items of this menu group are indicated by the "SNS:" code.
 Press enter to select menu,

edit using arrow keys (see next page). Confirm (and proceed) by pressing **enter**.

6) Exit: Press **meas** key until the [meas] mode indicator is displayed.




5		Configuration
Menu item	Action	Choices
TAG	Select ON or OFF using ▲ ▼ keys. Press enter to confirm. When switched on, the entry for "TAG" in the Memosens sensor is com- pared to the entry in the analyzer. If the entries differ, a mes- sage will be generated.	ON/ OFF
GROUP	Select ON or OFF using ▲ ▼ keys. Press enter to confirm. Function as described above	ON/ OFF

Sensor Verification (TAG, GROUP)

When Memosens sensors are calibrated in the lab, it is often useful and sometimes even mandatory that these sensors will be operated again at the same measuring points or at a defined group of measuring points. To ensure this, you can save the respective measuring point (TAG) or group of measuring points (GROUP) in the sensor. TAG and GROUP can be specified by the calibration tool or automatically entered by the transmitter. When connecting an MS sensor to the transmitter, it can be checked if the sensor contains the correct TAG or belongs to the correct GROUP. If not, a message will be generated, Sensoface gets "sad", and the display backlighting turns purple (magenta). The "sad" Sensoface icon can also be signaled by a 22 mA error current. Sensor verification can be switched on in the Configuration in two steps as TAG and GROUP if required.

When no measuring point or group of measuring points is saved in the sensor, e.g., when using a new sensor, Stratos enters its own TAG and GROUP. When sensor verification is switched off, Stratos always enters its own measuring point and group. A possibly existing TAG/GROUP will be overwritten.

Current Output 1 Output current range, current start, current end




3		conngaration
Menu item	Action	Choices
Process variable	Select using ▲ ▼ keys: OXY: Oxy value TMP: Temperature Press enter to confirm.	OXY/TMP
Current start, current end	Modify digit using ▲ ▼ keys, select next digit using ◀ ▶ keys. Press enter to confirm.	000.00600% (OXY, Sensor 10) 0.0000150% (OXY, Sensor 01, 001 and Traces option) -20150 °C / -4302 °F (TMP)

For **process variables comprising several decades**, decimal point and dimension can be shifted using the **()** cursor keys.


Then, the desired number is entered using (up / down) and \checkmark \blacktriangleright .

For measurement in gases (GAS), this method is used to switch between ppm and % for volume concentration (10000 ppm = 1 %).

Assignment of measured values: current start and current end



Current Output 1 Adjusting the time interval of the output filter




5		configuration
Menu item	Action	Choices
Time averaging filter	Enter value using ▲ ▼ ◀ ▶ keys.	0120 SEC (0000 SEC)
	Press enter to confirm.	


Time averaging filter

To smoothen the current output, a low-pass filter with adjustable filter time constant can be switched on. When there is a jump at the input (100 %), the output level is at 63 % after the time interval has been reached. The time interval can be set from 0 to 120 sec. If the time interval is set to 0 sec, the current output directly follows the input. **Note:**

The filter only acts on the current output, not on the display! During HOLD the filter is not applied. This prevents a jump at the output.




Current Output 1 Output current for error message or Sensoface alert






5		configuration
Menu item	Action	Choices
Output current for error message (FAIL)	In the case of an error (FAIL), the current output is set to 22 mA.	ON/ OFF
	Select ON or OFF using ▲ ▼ keys. Press enter to confirm.	
Output current for Sensoface (FACE)	In the case of a Sensoface alert (FACE), the current output is set to 22 mA.	ON/ OFF
	Select ON or OFF using ▲ ▼ keys. Press enter to confirm.	



Error messages and Sensoface alerts can be set separately for both current outputs. This allows, for example, signaling error messages only over current output 1 and Sensoface alerts only over current output 2.


Current Output 1 Output current during HOLD



- 1) Press menu key.
- 2) Select **CONF** using **↓** keys, press **enter**.
- Select OUT1 menu using → keys, press enter.
- 5) All items of this menu group are indicated by the "OT1:" code.


Press **enter** to select menu, edit using arrow keys (see next page). Confirm (and proceed) by pressing **enter**.

6) Exit: Press **meas** key until the [meas] mode indicator is displayed.




		configuration
Menu item	Action	Choices
Output current during HOLD	LAST: During HOLD the last measured value is maintained at the output. FIX: During HOLD a value (to be entered) is main- tained at the output. Select using ▲ ▼ Press enter to confirm.	LAST/FIX
Output current for HOLD FIX	Only with FIX selected: Enter current which is to flow at the output during HOLD Enter value using ▲ ▼ ◀ ▶ keys. Press enter to confirm.	00.0022.00 mA (21.00 mA)

Output signal during HOLD:




Current Output 2 Process variable. Current start. Current end ...



5		Configuration
Menu item	Action	Choices
Process variable	Select using ▲ ▼ keys: OXY: Oxy value TMP: Temperature Press enter to confirm.	OXY/ TMP

All the following adjustments are made as for current output 1 (see there)!


Correction Salinity correction, pressure correction, current input



- 1) Press menu key.
- 2) Select **CONF** using **↓** keys, press **enter**.
- Select CORRECTION menu using < ► keys, press enter.
- 5) All items of this menu group are indicated by the "COR:" code.


Press **enter** to select menu, edit using arrow keys (see next page). Confirm (and proceed) by pressing **enter**.

6) Exit: Press **meas** key until the [meas] mode indicator is displayed.



5		Configuration
Menu item	Action	Choices
Enter salinity	Enter salinity of the process medium. Enter value using ▲ ▼ ◀ ▶ keys. Press enter to confirm.	00.0045.00 ppt
Enter pressure unit	Select desired pressure unit using ▲ ▼ keys. Press enter to confirm.	Bar /kPa/PSI
Enter pressure correction	Select desired procedure for pressure correction using ▲ ▼ keys: MAN: Manual specifica- tion EXT: External pressure correction via current input Press enter to confirm.	MAN / EXT
(Manual pressure input)	Enter value using ▲ ▼ ▲ ▶ keys. Press enter to confirm.	Input range: 0.0009.999 BAR / 000.0999.9 KPA / 000.0145.0 PSI 1.013 BAR
Current input/ Pressure range	With external pressure input, select current input 0/4 20 mA and the pressure parameters for current start and end using $\checkmark \checkmark \checkmark$ keys.	0(4)20 mA 0.0009.999 Bar / 000.0999.9 kPa / 000.0999.9 PSI


CONTROL Input Parameter set selection via external signal




5		Configuration
Menu item	Action	Choices
Select function of CONTROL input	Select using ◀ ▶ keys. Press enter to confirm.	PARSET FIX A / MANUAL / CNTR INPUT (selecting parameter set A/B via signal at CONTROL input)

External switchover of parameter sets

The parameter set A/B can be activated from outside by sending a signal to the CONTROL input (e.g. from the process control system).



CONTROL Input Flow measurement



Со	nfig	gu	rati	ion

5		Configuration
Menu item	Action	Choices
Select function of CONTROL input	Select using ▲ ▼ keys. Press enter to confirm.	PARSET (selecting parameter set A/B via signal at CONTROL input)
		Flow (for connecting a pulse- output flow meter)
Adjust to flow meter:	With "Flow" selected, you must adjust the device to the flow meter used. Enter value using arrow keys. Press enter to confirm.	12000 pulses/liter

In the alarm menu you can configure flow monitoring. When you have set CONTROL to FLOW, you can specify 2 additional limit values for maximum and minimum flow.

If the measured value lies outside this range, an alarm message and a 22-mA error signal (if configured) will be generated.

Display

Flow measurement in measuring mode


Display

Flow measurement (sensor monitor)






Alarm Settings Alarm delay, Sensocheck



- 1) Press menu key.
- 2) Select **CONF** using **↓** keys, press **enter**.
- 3) Select parameter set using ◀ ▶ keys,
- 4) Select ALARM menu using ◀ ▶ keys, press enter.
- 5) All items of this menu group are indicated by the "ALA:" code.

Press enter to select menu, edit using arrow keys (see next page). Confirm (and proceed) by pressing **enter**.

6) Exit: Press meas key until the [meas] mode indicator is displayed.




		conngulation
Menu item	Action	Choices
Alarm delay	Enter alarm delay using ▲ ▼ ◀ ▶ keys. Press enter to confirm.	0600 SEC (010 SEC)
Sensocheck	Select Sensocheck (con- tinuous monitoring of sensor membrane and lines). Select ON or OFF using ▲ ▼ keys. Press enter to confirm. (At the same time, Sensoface is activated. With OFF, Sensoface is also switched off.)	ON/ OFF

Error messages can be signaled by a 22 mA output current (see Error Messages and Configuration of Output 1/Output 2).

The **alarm delay time** delays the color change of the display backlighting to red and the 22 mA signal (if configured).


Alarm Settings CONTROL input (FLOW MIN, FLOW MAX)



- 1) Press menu key.
- 2) Select **CONF** using **↓** keys, press **enter**.
- 3) Select parameter set using ◀ ▶ keys, press enter.
- 4) Select ALARM menu using ◀ ▶ keys, press enter.
- 5) All items of this menu group are indicated by the "ALA:" code.

Press enter to select menu, edit using arrow keys (see next page). Confirm (and proceed) using enter.

6) End: Press meas key until the [meas] mode indicator is displayed.




Configuration

		configuration
Menu item	Action	Choices
CONTROL input	The CONTROL input can generate an alarm when assigned to FLOW (flow monitoring) in the CONF menu: FLOW CNTR Flow measurement: allows monitoring the minimum and maximum flow (pulse counter)	ON/ OFF (FLOW MIN, FLOW MAX.)
Alarm Minimum flow FLOW MIN	Specify value	Default: 05.00 liters/h
Alarm Maximum flow FLOW MAX	Specify value	Default: 25.00 liters/h


Configuration

Time and Date Measuring Points (TAG/GROUP)





- 1) Press menu key.
- Select CONF using < → , press enter.
- 3) Select parameter set A using ◀ ► keys, press **enter**.
- Select CLOCK or TAG using → keys, press enter.
- 5) All items of this menu group are indicated by the "CLK:" or "TAG" code.
 Press enter to select menu, edit using arrow keys (see next page).
 Confirm (and proceed) by pressing enter.
- 6) Exit: Press **meas** key until the [meas] mode indicator is displayed.



Time and Date

Control of the calibration and cleaning cycles is based on the time and date of the integrated real-time clock.

In measuring mode the time is shown in the lower display. When using digital sensors, the calibration data is written in the sensor head. In addition, the logbook entries (cf Diagnostics) are provided with a time stamp.

Note:

There is no automatic switchover from winter to summer time! Be sure to manually adjust the time!

Sensor Verification (TAG, GROUP)

When Memosens sensors are calibrated in the lab, it is often useful and sometimes even mandatory that these sensors will be operated again at the same measuring points or at a defined group of measuring points. To ensure this, you can save the respective measuring point (TAG) or group of measuring points (GROUP) in the sensor. TAG and GROUP can be specified by the calibration tool or automatically entered by the transmitter. When connecting an MS sensor to the transmitter, it can be checked if the sensor contains the correct TAG or belongs to the correct GROUP. If not, a message will be generated, Sensoface gets "sad", and the display backlighting turns purple (magenta). The "sad" Sensoface icon can also be signaled by a 22 mA error current. Sensor verification can be switched on in the Configuration in two steps as TAG and GROUP if required.

When no measuring point or group of measuring points is saved in the sensor, e.g., when using a new sensor, Stratos enters its own TAG and GROUP. When sensor verification is switched off, Stratos always enters its own measuring point and group. A possibly existing TAG/GROUP will be overwritten.

Menu item	Action	Choices
Measuring point (TAG)	In the lower display line you can enter a designation for the measuring point (TAG) and for a group of mea- suring points (GROUP) if applicable. Up to 32 digits are possible. By pressing meas (repeatedly) in the measuring mode you can view the tag number. Select character using ▲ ▼ keys, select next digit using ∢ ▶ keys. Press enter to confirm.	AZ, 09, - + < > ? / @ The first 10 characters are seen in the display with- out scrolling.


Digital Sensors

Stratos Pro can be operated with digital sensors. Due to the galvanic isolation of Memosens sensors, earth or ground potentials have no effect here. Therefore, a Solution Ground or measures for equipotential bonding are not required.

Digital sensors can be calibrated and maintained in the lab. This considerably simplifies on-site maintenance.

Memosens Sensors: Calibration and Maintenance in the Lab

The "MemoSuite" software allows calibrating Memosens sensors under reproducible conditions at a PC in the lab. The sensor parameters are registered in a database. Documenting and archiving meet the demands of FDA CFR 21 Part 11. Detailed reports can be output as csv export for Excel.



MemoSuite Advanced)	Rent Hereit		ednamener 12 555 MB ennamener 20100518	Knick
filestender	4	100000000000	HERE		p+Data
	Sensor (pr (Gies)) sucrem (4 Stock pr (Gies umm 2 umm 2			West 2	pri Sie KM Jane N. JULIOWEDI Water N. JULIOWEDI Water N. JULIOWED Strate N. JULIO Water N. JULIO Water N. JULIO

Calibration history of several sensors



Digital Sensors

The comprehensive display options of the software allow drawing conclusions on the aging behavior of the sensors at one glance and making a reliable forecast for predictive maintenance.

The software is available as "Basic" (calibration function) or "Advanced" (with sensor database) version: www.knick.de

History: Load diagrams of the sensors

Memosens Sensors: Configuring the Device

The sensor type is selected during **Configuration**. The device only switches to measuring mode when the connected sensor corresponds to the type configured (Sensoface is friendly):



Otherwise, an error message is released. The **info** icon is displayed. You can display the error text in the bottom line using the ◀ ▶ keys.

Digital Sensors

Connecting a Digital Sensor

Step	Action/Display	Remark
Connect sensor		Before a digital sensor is connected, the error message "No sensor" is displayed.
Wait until the sensor data are displayed.	SEAS I DENTIFICATION	The hourglass in the display blinks.
Check sensor data	SEASENS MEMOSENS View sensor information using ↓ keys, press enter to confirm.	Display color changes to green. Sensoface is friendly when the sensor data are okay.
Go to measuring mode	Press meas , info or enter	After 60 sec the device automatically returns to measuring mode (time- out).

Replacing a Sensor

A sensor should only be replaced during HOLD mode to prevent unintended reactions of the outputs or contacts. When you first want to calibrate the new sensor, it can also be replaced in calibration mode.

Digital Sensors

Step	Action/Display	Remark
Select HOLD mode	Press menu key to call the selection menu, select HOLD using the ◀ ▶ keys, press enter to confirm.	Now the device is in HOLD mode. The HOLD mode can also be activated externally via the HOLD input. During HOLD the output current is frozen at its last value or set to a fixed value.
Disconnect old sensor, connect new sensor.		Temporary messages are dis- played during the replacement but neither output to the alarm contact nor entered in the log- book.
Wait until the sensor data are displayed.		
Check sensor data	SESSENS MEMOSENS View sensor informa- tion using ← ▶ keys, press enter to confirm.	You can view the sensor manu- facturer and type, serial number, and last calibration date.
Check measured values, then exit HOLD.	Hit meas key: Return to the selec- tion menu. Hold meas key depressed: Device switches to measuring mode.	The sensor replacement is entered in the extended logbook.

Calibration

Calibration adapts the device to the individual sensor characteristics. It is always recommended to calibrate in air.

Compared to water, air is a calibration medium which is easy to handle, stable, and thus safe. In the most cases, however, the sensor must be removed for a calibration in air.

When dealing with biotechnological processes which require sterile conditions, the sensor cannot be removed for calibration. Here, calibration must be performed with aeration directly in the process medium (e.g. after sterilization).

In the field of biotechnology, for example, often saturation is measured and calibration is performed in the medium for reasons of sterility.

For other applications where concentration is measured (water control etc.), calibration in air has proved to be useful.

Note:

- All calibration procedures must be performed by trained personnel. Incorrectly set parameters may go unnoticed, but change the measuring properties.
- If a 2-point calibration is prescribed, the zero calibration should be performed prior to slope calibration.

process randor					
Process variable	2	Calibration	Default rel. humidity	Default cal pressure	
Saturation (%)	SAT	Water	+100 %	Process pressure	
Concentration (mg/l, ppm)	Conc	Air	50 %	1.013 bar	

Common combination: process variable / calibration medium

The calibration procedures for these two common applications are described on the following pages. Of course, other combinations of process variable and calibration medium are possible.

Selecting a Calibration Mode

Calibration is used to adapt the device to the individual sensor characteristics, namely zero and slope.

Access to calibration can be protected with a passcode (SERVICE menu).

First, you open the calibration menu and select the calibration mode:

CAL_WTR / CAL_AIR	Calibration in air-saturated water / air (as configured)
CAL_ZERO	Zero calibration
P_CAL	Product calibration (calibration with sampling)
CAL-RTD	Temperature probe adjustment

Zero Calibration

The sensor models SE 704, SE 705, SE 706, SE 707 and InPro6000 have very low zero currents. Therefore, a zero calibration is only recommended for measurement of oxygen traces.

When a zero calibration is performed, the sensor should remain for at least 10 to 30 minutes in the calibration medium in order to obtain stable, non-drifting values.

During zero calibration, a drift check is not performed. Zero current of a properly functioning sensor is notably less than 0.5 % of air current. The display (bottom: measured value, top: entered value) does not change until an input current is entered for the zero point.

When measuring in an oxygen-free medium, the displayed current can be taken directly.

Zero Calibration

Disclass		Demende
Display	Action	Remark
	Select calibration, proceed by pressing enter	
ZERO POINT	Ready for calibration. Hourglass blinks. Place sensor in oxygen- free medium	Display (3 sec) Now the device is in HOLD mode.
	Upper display line: Zero current. Press enter to save this value or correct using arrow keys and then save by pressing enter . Lower display line: Sensor current measured	
	Display of slope Display of new zero current. End calibration by pressing enter key, place sensor in process	Sensoface display
	The oxygen value is shown in the upper dis- play line, "enter" blinks. Stop Hold by pressing enter .	New calibration: Select REPEAT, press enter key.
	Quit by pressing enter .	After end of calibra- tion, the outputs re- main in HOLD mode for a short time.

Product Calibration

Calibration with sampling

During product calibration the sensor remains in the process. The measurement process is only interrupted briefly.

Procedure: During sampling the currently measured value is stored in the device. The device immediately returns to measuring mode.

The cal mode indicator blinks and reminds you that calibration has not been terminated. The reference value is measured on the site, e.g. using a portable DO meter in a bypass.

This value is then entered in the device. The new value for slope or zero is calculated from the stored value and the reference value. From the measured value, the device automatically recognizes whether a new slope or zero must be calculated (above approx. 5 % saturation: slope, below: zero).

If the sample is invalid, you can take over the measured value saved during sampling instead of the reference value. In that case the old calibration values remain stored. Afterwards, you can start a new product calibration. The following describes a product calibration with slope correction – a product calibration with zero correction is performed correspondingly.

Display	Action	Remark
	Select calibration, then product calibration P_CAL. Press enter to proceed.	
PRODUCT STEP 1	Ready for calibration. Hourglass blinks.	Display (3 sec) Now the device is in HOLD mode.
LICRE VALUE	Take sample and save value. Press enter to proceed.	Now the sample can be measured. If the value is already available, press info+enter to proceed to step 2.

Product Calibration

Display	Action	Remark
■ ■ 190475 ■ ■ ■ ■ ■ ■ ■ ■ ■ ■ ■ ■ ■	The device returns to measuring mode.	From the blinking CAL mode indicator you see that product calibration has not been terminated.
PRODUCT STEP 2	Product calibration step 2: When the sample value has been determined, open the product cali- bration once more	Display (3 sec) Now the device is in HOLD mode.
	The stored value is displayed (blinking) and can be overwritten with the lab value. Press enter to proceed.	
	Display of new slope and zero. Sensoface is active. Press enter to proceed.	Related to 25 °C and 1013 mbar
	Display of new oxy value. Sensoface is active. To end calibration: Select MEAS, then enter	Repeat calibration: Select REPEAT, then enter
	End of calibration	After end of calibra- tion, the outputs re- main in HOLD mode for a short time.

Slope Calibration (Medium: Water)

(air-saturated)

Display	Action	Remark
	Select calibration (SLOPE). Immerse sensor in cal medium, start by pressing enter	"CAL WATER" or "CAL AIR" is selected in the configuration.
	Enter cal pressure Press enter to proceed.	Default: 1.000 bar Unit bar/kpa/PSI
	Drift check: Display of: Sensor current (nA) Response time (s) Temperature (°C/°F)	Device goes to HOLD mode. The drift check might take some time.
	Display of calibration data (slope and zero) and Sensoface Press enter to proceed.	Related to 25 °C and 1013 mbar
	Display of selected process value. To end calibration: Select MEAS using ◀ ▶, then enter	To repeat calibra- tion: Select REPEAT using ◀ ▶, then enter
37E [000] 37E	Place sensor in process. End of calibration	After end of calibra- tion, the outputs re- main in HOLD mode for a short time.

Slope Calibration (Medium: Air)


D'		· /
Display	Action	Remark
MEDIUM RIR	Select calibration. Place sensor in air, press enter to start. Device goes to HOLD mode.	"CAL WATER" or "CAL AIR" is selected in the configuration.
	Enter relative humidity using arrow keys Press enter to proceed.	Default for relative humidity in air: rH = 50%
	Enter cal pressure using arrow keys Press enter to proceed.	Default: 1.000 bar Unit bar/kpa/PSI
	Drift check: Display of: Sensor current (nA) Response time (s) Temperature (°C/°F) Press enter to proceed.	The drift check can take some minutes.
	Display of calibration data (slope and zero). Press enter to proceed.	
	Display of selected process variable (here: %vol). Now the device is in HOLD mode: Reinstall the sensor and check whether the message is OK. MEAS ends calibration, REPEAT permits repetition.	After end of calibra- tion, the outputs re- main in HOLD mode for a short time.

Temp Probe Adjustment

Display	Action	Remark
	Select temp adjust- ment. Press enter to proceed.	Wrong settings change the measurement properties!
	Measure the tem- perature of the process medium using an exter- nal thermometer.	Display (3 sec) Now the device is in HOLD mode.
25.0 °€ Aluus: 235°€, 	Enter the measured temperature value. Maximum difference: 10 K. Press enter to proceed.	Display of actual temperature (un- compensated) in the lower display.
	The corrected tempera- ture value is displayed. Sensoface is active. To end calibration: Select MEAS, then enter To repeat calibration: Select REPEAT, then enter	After end of calibra- tion, the outputs re- main in HOLD mode for a short time.
	After calibration is ended, the device will switch to measuring mode.	

Measurement

Display




Remark

From the configuration or calibration menus, you can switch the device to measuring mode by pressing the **meas** key.

(Waiting time for signal stabilization approx. 8 sec). In the measuring mode the main display shows the configured process variable (Oxy [%] or temperature), the secondary display shows the time and the second configured process variable (Oxy [%] or temperature). The [meas] mode indicator lights and the active parameter set (A/B) is indicated.

By pressing the **meas** key you can step through the following displays. When no key has been pressed for 60 sec, the device returns to the MAIN DISPLAY.





 Selecting the parameter set (if set to "manual" in the configuration).
 Select the desired parameter set using the < → arrow keys (PARSET A or PARSET B blinks in the lower display line).
 Press enter to confirm.

Further displays (each by pressing **meas**).

2) Display of tag number ("TAG")

- 3) Display of time and date
- 4) Display of output current(s)

In the Diagnostics mode you can access the following menus without interrupting the measurement:

CALDATA	viewing the calibration data
SENSOR	viewing the sensor data
SELFTEST	starting a device self-test
LOGBOOK	viewing the logbook entries
MONITOR	displaying currently measured values
VERSION	displaying device type, software version, serial number


Access to diagnostics can be protected with a passcode (SERVICE menu).

Note:

HOLD is not active during Diagnostics mode!

Action	Key	Remark
Activate Diagnostics	menu	Press menu key to call the selection menu. (Display color changes to turquoise.) Select DIAG using ◀ ▶ keys, confirm by pressing enter .
Select diagnostics option		Use () keys to select from: CALDATA SENSOR SELFTEST LOGBOOK MONITOR VERSION See next pages for further proceeding.
Exit	meas	Exit by pressing meas .

Display



Menu item

Displaying the calibration data

Select CALDATA using ↓ , confirm by pressing **enter**. Use the ↓ keys to select the desired parameter from the bottom line of the display: (LAST_CAL ZERO SLOPE NEXT_CAL). The selected parameter is shown in the main display.

Press meas to return to measurement.

Displaying the sensor data

For analog sensors, the type is displayed, for digital sensors, the manufacturer, type, serial number and last calibration date. In each case Sensoface is active.

Display data using ◀ → keys, press **enter** or **meas** to return.

Display











Menu item

Device self-test

(To abort, you can press meas.)

- Display test: Display of all segments with changing background colors (white/green/red). Press enter to proceed.
- RAM test: Hourglass blinks, then display of --PASS-- or --FAIL--Press enter to proceed.
- EEPROM test: Hourglass blinks, then display of --PASS-- or --FAIL--Press enter to proceed.
- FLASH test: Hourglass blinks, then display of --PASS-- or --FAIL--Press enter to proceed.
- Module test: Hourglass blinks, then display of --PASS-- or --FAIL--Press enter or meas to return to measuring mode.

Display







Menu item

Displaying the logbook entries

Select LOGBOOK using ◀ ▶, press **enter** to confirm.

Using the ▲ keys, you can scroll backwards and forwards through the logbook (entries -00-...-99-), -00- being the last entry.

If the display is set to date/time, you can search for a particular date using the ▲ ▼ keys. Press ◀ ▶ to view the corresponding message text.

If the display is set to the message text, you can search for a particular message using the ▲ ▼ keys. Press ◀ ▶ to display the date and time.

Press meas to return to measurement.



Extended logbook / Audit Trail (via TAN)

Using the ▲ keys, you can scroll backwards and forwards through the extended logbook (entries -000-...-199-), -000- being the last entry.

Display: CFR

Audit Trail also records function activations (CAL CONFIG SERVICE), some Sensoface messages (cal timer, wear) and opening of the enclosure.

Display



Display example:











Menu item

Displaying the currently measured values (sensor monitor)

Select MONITOR using (), press **enter** to confirm. Use the () keys to select the desired parameter from the bottom line of the display: OXY, RTD, I-INPUT (for digital sensors in addition: OPERATION TIME SENSOR WEAR LIFETIME CIP SIP AUTOCLAVE). The selected parameter is shown in the main display. Press **meas** to return to measurement.

Display of directly measured value (for validation, sensor can be immersed in a calibration solution, for example, or the device is checked by using a simulator)

Display of remaining dynamic lifetime (for ISM sensors only)

Display of sensor operating time (for digital sensors only)

Display of sensor wear (Memosens only) When Sensocheck is activated, Sensoface will remind you to check the sensor and replace electrolyte and membrane. Info text: "Sensor wear - change membrane and electrolyte". After having carried out the servicing, reset the sensor wear counter in the Service menu.

Version

Display of device type, software/hardware version and serial number for all device components. Use the ▲ ▼ keys to switch between software and hardware version. Press enter to proceed to next device component. In the Service mode you can access the following menus:

	,
MONITOR	displaying currently measured values
SENSOR	displaying the sensor data,
	with MEMOSENS also resetting the sensor wear
	counter after replacement of electrolyte/membrane,
	incrementing the autoclaving counter
OUT1	testing current output 1
OUT2	testing current output 2
CODES	assigning and editing passcodes
DEFAULT	resetting the device to factory settings
OPTION	enabling options via TAN

Note:


HOLD is active during Service mode!

Action	Key/Display	Remark
Activate Service	menu	Press menu key to call the selection menu. Select SERVICE using ◀ ▶ keys, press enter to confirm.
Passcode	PASSCODE SERVI)	 Enter passcode "5555" for service mode using the ▲ ▼ ▲ ▶ keys. Press enter to confirm.
View	بر المحالي المحالي المحالي المحالي المحالي	 In service mode the following icons are displayed: [diag] mode indicator HOLD triangle Service (wrench)
Exit	meas	Exit by pressing meas .

Service

Menu item	Remark
	 Displaying currently measured values (sensor monitor) with HOLD mode activated: Select MONITOR using ↓ , press enter to confirm. Select variable in the bottom text line using ↓ . The selected parameter is shown in the upper display line. As the device is in HOLD mode, you can perform validations using simulators without influencing the signal outputs. Return to Service menu: Hold meas depressed for longer than 2 sec. Press meas once more to return to measurement.
× ¥ES Oxy: Reset wear ■	Sensor: Resetting the wear counter When you have replaced the electrolyte or the membrane of the OXY sensor, you should reset the wear counter. Default setting is "NO". Select "YES" and press enter to reset the wear counter.
	Incrementing the autoclaving counter After having completed an autoclaving process, you must increment the autoclaving count. To do so, select " YES " and confirm by pressing enter . The device confirms with "INCREMENT AUTOCLAVE CYCLE".
	 Specifying the current at outputs 1 and 2: Select OUT1 or OUT2 using the () keys, press enter to confirm. Enter a valid current value for the respective output using A < () keys. Press enter to confirm. For checking purposes, the actual output current is shown in the bottom right corner of the display. End by pressing enter or meas.

Service



Remark

Assigning passcodes:

Menu item

Releasing an option:

Options come with a "transaction number" (TAN). To release the option, enter this TAN and confirm by pressing **enter**.

Operating States


Operating status	OUT 1	OUT 2	Time out
Measuring			-
DIAG			60 s
CAL_ZERO Zero point			No
CAL_SLOPE Slope			No
P_CAL Product calibration S1			No
P_CAL Product calibration S2			No
CAL_RTD Temp adjustment			No
CONF_A			20
ParSet A			min
CONF_B			20
ParSet B			min
SERVICE MONITOR			20
			min
SERVICE OUT 1			20
			min
SERVICE OUT 2			20
			min
SERVICE CODES			20
			min
SERVICE DEFAULT			20
			min
SERVICE OPTION			20
			min
HOLD input			No
Explanation:	as config active		/Fix or Last/Off) anual

A2...X: Supply Units and Connection

Recommended Power Supply Units: Order No.:

Repeater power supply, Ex, 90253 V AC, output 420 mA	WG 21 A7
Repeater power supply, Ex, 90253 V AC, HART, output 420 mA	WG 21 A7 Opt. 470
Repeater power supply, Ex, 24 V AC/DC, output 420 mA	WG 21 A7 Opt. 336
Repeater power supply, Ex, 24 V AC/DC, HART, output 420 mA	WG 21 A7 Opt. 336, 470
Repeater power supply, non-Ex, 24 V DC, output 420 mA	IsoAmp PWR B 10116
Repeater power supply, non-Ex, 24 V DC, HART, output 0/420 mA / 010 V	IsoAmp PWR A 20100

Connection to Supply Units



Product Line and Accessories

Order Code Stratos Pro A 2...

									TAN
Example	A 2	0	1	X	-	OXY	-	1	
2-wire / 4-20 mA	A 2	1							B,C,E
<u> </u>	<u> </u>								D,C,L
Communication Without (HART retrofittable			1						
Without (HART retrofittable	via IAN)	0	_						A
Version number				_					
Version			1						
Approvals									
General Safety				Ν					
ATEX / IECEx Zone 2				В					
ATEX / IECEx / FM / CSA Zon	e 1 / Cl 1	Div 1		X					
Measuring channel									
Memosens pH / Redox	digital	-				MSPH			G
Memosens Cond	digital					MSCOND			
Memosens Condl	digital					MSCONDI			
Memosens Oxy	digital					MSOXY			
Dual COND (2x2-electrode s		naloo	a)	Ν		CC			
pH / ORP value	Measuri			le		PH			F, G
(ISM digital per TAN)		-							
Cond, 2-/4-electrode	Measuri					COND			
Conductivity, electrodeless						CONDI			
Oxygen (ISM digital and	Measuri	ng m	odu	le		OXY			D, F
traces per TAN)									
Options									
Without 2nd current output								0	
With 2nd current output								1	
TAN antions									
TAN options HART						SW-A001			(A)
Logbook						SW-A002			(A) (B)
Extended logbook (Audit Tr	ail)					SW-A002			(C)
Trace oxygen measurement						SW-A004			(C) (D)
Current input $+ 2$ digital inp						SW-A005			(E)
ISM digital	uts					SW-A006			(F)
Pfaudler						SW-A007			(G)
Mounting occurring									. ,
Mounting accessories						711 0074			
Pipe-mount kit ZU 0274 Protective hood ZU 0737									
Panel-mount kit						ZU 0737 ZU 0738			
						20 07 50			

Standard	Sensors: SE 706, SE 707, InPro 6	5800, Oxyferm, Memosens	
Input range	Meas. current 0 600 nA	Resolution 10 pA	
Measurement error	< 0.5% meas. val. + 0.05 nA + 0.005 nA/K		
Operating modes	GAS	Measurement in gases	
	DO	Measurement in liquids	
Display ranges	Saturation (-10 +80 °C / +14 +176 °F)	0.0 600.0 %	
	Concentration (-10 +80 °C / +14 +176 °F)	0.00 99.99 mg/l	
	(Dissolved oxygen)	0.00 99.99 ppm	
	Volume concentration in gas	0.00 99.99 %vol	
Polarization voltage	–400 –1000 mV		
	Default –675 mV (resolution <	5 mV)	
Permissible guard current	≤ 20 μA		
Traces (TAN SW-A004)	Sensors: SE 706/707; InPro 680	0/6900/6950; Oxyferm/Oxygold	
Input range I ¹⁾	Meas. current 0 600 nA Resolution 10 pA		
Measurement error	< 0.5% meas. val. + 0.05 nA + 0.005 nA/K		
Input range II ¹⁾	Meas. current 0 100000 nA Resolution 166 pA		
Measurement error	< 0.5% meas. val. + 0.8 nA + 0.008 nA/K		
Operating modes	GAS	Measurement in gases	
	DO	Measurement in liquids	
Ranges with standard sensors	"10"		
	Saturation (–10 +80 °C / +14 +176 °F)	0.0 600.0 %	
	Concentration (-10 +80 °C / +14 +176 °F)	0.00 99.99 mg/l	
	(Dissolved oxygen)	0.00 99.99 ppm	
	Volume concentration in gas	0.00 99.99 %vol	
Ranges with trace sensors "01	11		
(TAN SW-A004)	Saturation (–10 +80 °C / +14 +176 °F)	0.000 150.0 %	
	Concentration (-10 +80 °C / +14 +176 °F)	0000 9999 μg/l / 10.00 20.00 mg/l	
	(Dissolved oxygen)	0000 9999 ppb / 10.00 20.00 ppm	
	Volume concentration in gas	0000 9999 ppm / 1.000 50.00 %vol	

Ranges with trace sensors "001"

hanges when trace sensors		
(TAN SW-A004)	Saturation (−10 +80 °C / +14 +176 °F)	0.000 150.0 %
	Concentration (–10 +80 °C / +14 +176 °F)	000.0 9999 μg/l / 10.00 20.00 mg/l
	(Dissolved oxygen)	000.0 9999 ppb / 10.00 20.00 ppm
	Volume concentration in gas	000.0 9999 ppm / 1.000 50.00 %vol
Polarization voltage	0 –1000 mV	
	Default –675 mV (resolution <	5 mV)
Permissible guard current	≤ 20 μA	
Input correction	Pressure correction *	0.000 9.999 bar / 999.9 kPa / 145.0 PSI
		manually or through current input 0(4) 20 mA
	Salinity correction	0.0 45.0 g/kg
Sensor standardization *		
Operating modes *	AIR Automatic calibration in a	ir
	WTR Automatic calibration in	air-saturated water
	Product calibration	
	Zero calibration	
Calibration range	Zero point	± 2 nA
Standard sensor "10"	Slope	25 130 nA (at +25°C/+77°F, 1013 mbar)
Calibration range	Zero point	±2nA
Trace sensor "01"	Slope	200550 nA (at +25°C/+77°F, 1013 mbar)
Calibration range	Zero point	± 3 nA
Trace sensor "001"	Slope	20009000 nA (at 25°C/+77°F, 1013 mbar)
Calibration timer *	Interval 0000 9,999 h	
Pressure correction *	Manual 0.000 9.999 bar / 99	9.9 kPa / 145.0 PSI
Sensocheck	Monitoring of membrane and circuits or open circuits (can b	electrolyte and the sensor wires for short e disabled)
Delay	Approx. 30 s	
Sensoface	Provides information on the se Evaluation of zero/slope, respo Sensocheck, can be disabled	ensor condition onse, calibration interval, wear,

Temperature input	NTC 22 k Ω / NTC 30 k Ω *		
	2-wire connection, adjustable		
Measuring range	-20.0 +150.0 °C / -4 +302 °F		
Adjustment range	10 К		
Resolution	0.1 °C / 0.1 °F		
Measurement error ^{2,3,4)}	< 0.5 K (< 1 K at > 100 °C)		
ISM input	"One wire" interface for operation with ISM (digital sensors)		
	(6 V / Ri= approx. 1.2 kΩ)		

l input (TAN)	Current input 0/4	20 mA / 50 Ω for external pres	ssure compensation
Start/end of scale	l Configurable 0 9.999 bar		
Characteristic	Linear		
Measurement error ^{1.3)}	< 1% current value + 0.1 mA		
HOLD input	Galvanically separated (optocoupler)		
Function	Switches device to HOLD mode		
Switching voltage	0 2 V AC/DC	HOLD inactive	
	10 30 V AC/DC	HOLD active	
CONTROL input	Galvanically separated (optocoupler)		
Function	Selecting parameter set A/B or flow measurement		
Parameter set A/B	Control input	0 2 V AC/DC 10 30 V AC/DC	Parameter set A Parameter set B
FLOW	Pulse input for flow measurement 0 100 pulses/s		
Message	via 22 mA		
Display	00.0 99.9 l/h		
Output 1	Current loop, 4 20 mA, floating, protected against inverse polarity HART communication (see further below for specifications)		
Supply voltage	14 30 V		
Process variable *	Saturation, concentration, salinity or temperature		
Characteristic	Linear		
Overrange *	22 mA in the case of error messages		
Output filter *	PT ₁ filter, time constant 0 120 s		
Measurement error ¹⁾	< 0.25 % current value + 0.025 mA		
Start/end of scale *	Configurable within	n selected range	

Output 2	Current loop, 4 20 mA, floating, protected against inverse polarity	
Supply voltage	14 30 V	
Process variable *	Saturation, concentration, salinity or temperature	
Characteristic	Linear	
Overrange *	22 mA in the case of error messages	
Output filter *	PT ₁ filter, time constant 0 120 s	
Measurement error ¹⁾	< 0.25 % of current value + 0.05 mA	
Start/end of scale *	Configurable within selected range	
Real-time clock	Different time and date formats selectable	
Power reserve	> 5 days	
Display	LC display, 7-segment with icons	
Main display	Character height approx. 22 mm, unit symbols approx. 14 mm	
Secondary display	Character height approx. 10 mm	
Text line	14 characters, 14 segments	
Sensoface	3 status indicators (friendly, neutral, sad face)	
Mode Indicators	meas, cal, conf, diag	
	Further icons for configuration and messages	
Alarm indication	Display blinks, red backlighting	
Keypad	Keys: meas, menu, info, 4 cursor keys, enter	
HART communication	HART version 6 Digital communication by FSK modulation of output current 1	
	Device identification, measured values, status and messages, parameter setting, calibration, records	
FDA 21 CFR Part 11	Access control by editable passcodes Logbook entry and flag via HART Message and logbook entry when enclosure is opened	

Diagnostics functions	l	
Calibration data	Calibration date, zero, slope	
Device self-test	Display test, automatic memory test (RAM, FLASH, EEPROM)	
Logbook	100 events with date and time	
Extended logbook (TAN)	Audit Trail: 200 events with date and time	
Service functions		
Sensor monitor	Display of direct sensor signals	
Current source	Current specifiable for output 1 and 2 (04.00 22.00 mA)	
Passcodes	Assigning passcodes for menu access	
Factory setting	Resetting all parameters to factory setting	
TAN	Enabling optionally available additional functions	
Explosion protection	See Control Drawing or www.knick.de	
(A2**B/X)		
Data retention	Parameters, calibration data, logbook > 10 years (EEPROM)	
EMC	EN 61326-1 (General Requirements)	
Emitted interference	Class B (residential area)	
Immunity to interference	Industry EN 61326-2-3	
Nominal operating conditions		
Ambient temperature	–20 +65 °C / -4 +149 °F	
Transport/Storage temperature	–30 +70 °C / -22 +158 °F	
Relative humidity	10 95% not condensing	
Supply voltage	14 30 V	

Enclosure	Molded enclosure made of glass-reinforced PBT, PC
Mounting	Wall, pipe/post or panel mounting
Color	Gray, RAL 7001
Ingress protection	IP 67, NEMA 4X
Flammability	UL 94 V-0
Dimensions	148 mm x 148 mm
Control panel cutout	138 mm x 138 mm to DIN 43 700
Weight	Approx. 1200 g
Cable glands	l 3 knockouts for M20 x 1.5 cable glands
	2 knockouts for NPT ½" or rigid metallic conduit
Connections	Terminals, conductor cross-section max. 2.5 mm ²
*) User-defined	1) Acc. to EN 60746, at nominal operating conditions
2) \pm 1 count	3) Plus sensor error

Error Handling

Alarm condition:

- The display backlighting turns red
- The alarm icon 🚺 is displayed
- The complete measured-value display blinks
- "ERR xxx" is displayed in the lower menu line
- Press the [info] key to view a short error text:
- The error text appears in the lower menu line
- The main display reads "InFo".

Parameter errors:

Configuration data such as current range, limit values, etc are checked during the input.

If they are out of range,

- "ERR xxx" is displayed for 3 sec,
- · the display backlighting flashes red,
- the respective maximum or minimum value is shown,
- input must be repeated.

If a faulty parameter arrives through the interface (HART),

- an error message will be displayed: "ERR 100...199"
- the faulty parameter can be localized by pressing the [info] key

Calibration errors:

If errors occur during calibration,

• an error message will be displayed

Sensoface:

If the Sensoface becomes sad,

- the display backlighting will turn purple
- the cause can be seen by pressing the info key
- the calibration data can be seen in the Diagnostics menu

Error Messages

Error	Info text (is displayed in case of fault when the Info key is pressed)	Problem Possible causes
ERR 99	DEVICE FAILURE	Error in factory settings EEPROM or RAM defective This error message only occurs in the case of a total defect. The device must be repaired and recalibrated at the factory.
ERR 98	CONFIGURATION ERROR	Error in configuration or calibration data Memory error in device program Configuration or calibration data defective; completely reconfig- ure and recalibrate the device.
ERR 97	NO MODULE INSTALLED	No module Please have the module replaced in the factory.
ERR 96	WRONG MODULE	Wrong module Please have the module replaced in the factory.
ERR 95	SYSTEM ERROR	System error Restart required. If error still persists, send in the device for repair.
ERR 01	NO SENSOR	O₂ sensor * Sensor defective Sensor not connected Break in sensor cable
ERR 02	WRONG SENSOR	Wrong sensor *
ERR 04	SENSOR FAILURE	Failure in sensor *

Error Messages

Error	Info text (is displayed in case of fault when the Info key is pressed)	Problem Possible causes
ERR 05	CAL DATA	Error in cal data *
ERR 11	RANGE DO SATURATION	Display range violation SAT saturation CONC concentraton or GAS volume concentration
ERR 12	SENSOR CURRENT RANGE	Measuring range of sensor exceeded
ERR 13	TEMPERATURE RANGE	Temperature range violation
ERR 15	SENSOCHECK	Sensocheck
ERR 60	OUTPUT LOAD	Load error
ERR 61	OUTPUT 1 TOO LOW	Output current 1 < 3.8 mA
ERR 62	OUTPUT 1 TOO HIGH	Output current 1 > 20.5 mA
ERR 63	OUTPUT 2 TOO LOW	Output current 2 < 3.8 mA
ERR 64	OUTPUT 2 TOO HIGH	Output current 2 > 20.5 mA

* Memosens or ISM sensors

Error Messages

Error	Info text (is displayed in case of fault when the Info key is pressed)	Problem Possible causes
ERR 72	FLOW TOO LOW	Flow too low
ERR 73	FLOW TOO HIGH	Flow too high
ERR 105	INVALID SPAN I-INPUT	I-Input configuration error

Sensoface

(Sensocheck must have been activated during configuration.)



The smiley in the display (Sensoface) alerts to sensor problems (defective sensor, sensor wear, defective cable, maintenance request). The permitted calibration ranges and the conditions for a friendly, neutral, or sad Sensoface are summarized in the following table. Additional icons refer to the error cause.

Sensocheck

Continuously monitors the sensor and its wiring. Critical values make the Sensoface "sad" and the corresponding icon blinks:



The Sensocheck message is also output as error message Err 15. The display backlighting turns red, output current 1 is set to 22 mA (when configured correspondingly).

Sensocheck can be switched off during configuration (then Sensoface is also disabled).

Exception:

After a calibration a smiley is always displayed for confirmation.

Note:

The worsening of a Sensoface criterion leads to the devaluation of the Sensoface indicator (Smiley becomes "sad"). An improvement of the Sensoface indicator can only take place after calibration or removal of the sensor defect.

Sensoface

Display	Problem	Status	
SLOPE #	Zero and slope		Zero and slope of the sensor are still okay. The sensor should be replaced soon.
			Zero and/or slope of the sensor have reached values which no longer ensure prop- er calibration. Replace sensor.
X	Calibration timer	•••	Over 80 % of the calibration interval has already past.
		:	The calibration interval has been exceeded.
S	Sensor defect		Check the sensor and its con- nections (see also Err 15, Error Messages).
C	Response time		Sensor response time has increased. The sensor should be replaced soon. To achieve an improvement, clean the sensor and check the electrolyte and membrane.
		:	Sensor response time has sig- nificantly increased (> 600 s, calibration aborted after 720 s) Check electrolyte and mem- brane, replace sensor if required.

Sensoface

Display	Problem	Status	
Æ	Sensor wear (for digital sensors only)	•••	Wear is over 80%. Check electrolyte and membrane.
			Wear is at 100%. Check electrolyte and mem- brane, replace if required. Note: Reset the wear counter in the SERVICE - SENSOR menu when you have replaced the membrane or electrolyte.
AUTOCLAVI OVERRUN	E CYCLES	claving c	y permitted number of auto- ycles has been reached. sensor or increment autoclaving
SIP CYCLES	OVERRUN	ing cycle	y permitted number of steriliz- s has been reached. sensor or increment SIP counter.
CIP CYCLES	OVERRUN	cycles ha	y permitted number of cleaning s been reached. sensor or increment CIP counter.

Conformity with FDA 21 CFR Part 11

In their directive "Title 21 Code of Federal Regulations, 21 CFR Part 11, Electronic Records; Electronic Signatures" the American health agency FDA (Food and Drug Administration) regulates the production and processing of electronic documents for pharmaceutical development and production. This results in requirements for measuring devices used for corresponding applications. The following features ensure that the measuring devices of this Series meet the demands of FDA 21 CFR Part 11:

Electronic Signature – Passcodes

Access to the device functions is regulated and limited by individually adjustable codes – "Passcodes" (see SERVICE). This prevents unauthorized modification of device settings or manipulation of the measurement results. Appropriate use of these passcodes makes them suitable as electronic signature.

Audit Trail

Every (manual) change of device settings can be automatically documented. Each change is tagged with a "Configuration Change Flag", which can be interrogated and documented using HART communication. Altered device settings or parameters can also be retrieved and documented using HART communication.

Extended logbook

Audit Trail also records function activations (CAL, CONFIG, SERVICE), some Sensoface messages (cal timer, wear) and opening of the enclosure.

A

Access code assignment 97 Access codes, table 124 Accessories 100 Activating an option 97 Alarm 30 Alarm and HOLD messages 31 Alarm delay 70 Alarm settings, CONTROL input 72 Ambulance TAN 97 Application in hazardous locations 10 Assembly 12 Audit Trail 115 Autoclaving counter: configuration 50 Autoclaving counter: description 51 Autoclaving counter: increment 96 Automatic pressure compensation 64

B

Backlighting 22 Block diagram 11

С

Calibration 80 Calibration and maintenance in the lab 76 Calibration data 91 Calibration errors 108 Calibration, general 27 Calibration medium: air/water 47 Calibration modes 81 Calibration timer, configuration 47 Calibration timer, Sensoface alert 113 CIP, cleaning cycles 49 Cleaning cycles: configuration 48 Configuration, alarm 70 Configuration, CIP/SIP settings 48 Configuration, CONTROL input 66 Configuration, correction 64 Configuration, current output 1 54

Configuration, current output 2 62 Configuration, general 27 Configuration, individual settings 41 Configuration, measuring point 74 Configuration, menu groups 33 Configuration, menu structure 32 Configuration, output current during HOLD 60 Configuration, output current for error message or Sensoface 58 Configuration, overview 35 Configuration, Sensocheck 70 Configuration, sensor 44 Configuration, sensor verification (TAG, GROUP) 52 Configuration, time and date 74 Configuring the device 77 Connection 78 Connection examples 18 Connection to supply units 99 CONTROL, alarm settings 72 **Control Drawings 3** CONTROL for flow measurement 68 CONTROL for parameter set selection 66 CONTROL input, messages 31 **CORRECTION menu 64** Current input for pressure compensation 64 Current output 1, configuring 54 Current output 2, configuring 62

D

Date and time (configuration) 74 Date and time (usage) 75 Date, display 89 Device self-test 92 Device type, display 94 Diagnostics 90 Diagnostics, calibration data 91 Diagnostics, device self-test 92 Diagnostics, general 27 Diagnostics, sensor data 91 Diagnostics, sensor monitor 94

Diagnostics, version 94 Dimensions 13 Display 22 Display backlighting 22 Display data in Diagnostics mode 90 Display test 92 Disposal 2 Documentation 3

Е

EEPROM test 92 Electronic Signature 115 Enabling an option 97 Enclosure 13 Enclosure components 12 Entering values 24 Error handling 108 Error messages 109 EU Declarations of Conformity 3 Extended logbook, Audit Trail 115 Extended logbook, diagnostics 93

F

FACE: Sensoface alert, 22 mA output current 59 FAIL: error message, 22 mA output current 59 FDA 21 CFR Part 11 115 FLASH test 92 FLOW 69 Flow measurement: configuration 68

G

GROUP (measuring points) 75

Η

HOLD, configuration 61 HOLD mode, description 29 HOLD mode, exit 29 HOLD mode, external activation 30 HOLD mode, manual activation 30 HOLD mode, output signal 29

I

Info text 109 Installation 16 Intended use 7

K

Keypad 21

L

Logbook, diagnostics 93

Μ

Manual pressure input 64 Measured values, display 94 Measuring mode 89 Measuring mode, overview 23 Measuring mode selection 44 Measuring points (TAG/GROUP) 75 Measuring range 55 Membrane compensation 44 MemoSuite software for calibrating Memosens sensors 76 Menu structure 28 Menu structure of configuration 32 Message via CONTROL input 31 Module test 92 Mounting plan 13 Mounting possibilities 7

0

Operating modes 27 Operating mode, selection 24 Operating states 98 Operation and connection 76 Option request 97 Options, overview 100 Order code 100 Output current, display 89 Output current for error message (FAIL) 59 Output current for Sensoface (FACE) 59 Output current range 2, configuring 62

Output current, specify value 96 Output filter: setting a time interval 56 Output signal during HOLD 29 Output signal during HOLD, configuration 61 Overview 7

Ρ

Package contents 12 Package contents, documentation 3 Panel mounting 15 Parameter error 108 Parameter set A/B 33 Parameter set A/B, display 89 Parameter set A/B, individual settings 42 Parameter set selection via external signal 66 Passcodes, table 124 Pipe mounting 14 Polarization voltage 44 Power supply units 99 Predictive maintenance (Memosens) 77 Pressure correction 64 Pressure unit, selecting 64 Process variable for current output 1 54 Process variable for current output 2 62 Product calibration 84 Product line 100 Protective hood 14

Q

Quickstart guides 3

R

RAM test 92 Rating plates 16 Registered trademarks 123 Reset to factory settings 97 Return of products under warranty 2

S

Safety information 10 Safety instructions 3 Salinity, entering 64 Selection menu 24 Sensocheck 112 Sensocheck, configuration 71 Sensoface 112 Sensoface alerts 59 Sensoface, troubleshooting 108 Sensor connection, assignments 17 Sensor connections, examples 18 Sensor data, display 91 Sensor defect 113 Sensor monitor (diagnostics) 94 Sensor monitor (Service) 96 Sensor type, analog/digital 44 Sensor verification (TAG, GROUP) 53 Sensor wear counter, resetting (Memosens) 96 Sensor wear, display (Memosens) 94 Sensor wear, Sensoface alert 114 Serial number, display 94 Service, factory setting 97 Service, general 27 Service, incrementing the autoclaving counter 96 Service mode 95 Service, output current, specify value 96 Service, passcode assignment 97 Service passcode lost 97 Service, sensor monitor 96 Setting the passcodes 97 Signal colors 22, 26 Signal lines 17 SIP, sterilization cycles 49 Slope calibration in air 87 Slope calibration in water 86 Slope calibration, selecting the medium 47 Software version, display 94

Solution Ground - and Memosens 76 Specifications 101 Specific test report 3 Start-up 10 Sterilization cycles: configuration 48 Supply units 99 Switchover of parameter sets A/B 34

Т

Tag number, display 89 TAG (point of measurement) 75 TAN input 97 TAN options, activation 97 TAN options, overview 100 Technical data 101 Temperature probe adjustment 88 Temperature probe selection 44 Terminal assignments 16 Terminals 16 Time and date (configuration) 74 Time and date (usage) 75 Time averaging filter 56 Time, display 89 Trademarks 123 Transaction number (TAN) 97

U

User interface 21

W

Weather protector 14 Wiring 17 Wiring examples 18 Wiring, power supply units 99

Z

Zero calibration 82

The following names are registered trademarks. For practical reasons they are shown without trademark symbol in this manual. Stratos[®]

Sensocheck®

Sensoface[®]

InPro® is a registered trademark of Mettler-Toledo AG.

ISM[®] is a registered trademark of Mettler-Toledo AG.

Memosens[®] is a registered trademark of Endress+Hauser Conducta GmbH and Knick Elektronische Messgeräte GmbH & Co. KG.

HART[®] is a registered trademark of the HART Communication Foundation.

Passcodes

In the SERVICE – CODES menu you can assign passcodes to protect the access to certain functions.

Mode of operation	Passcode
Service (SERVICE)	5555
Diagnostics (DIAG)	
HOLD mode	
Calibration (CAL)	
Configuration (CONF)	

Knick Elektronische Messgeräte GmbH & Co. KG

Beuckestraße 22 14163 Berlin Germany

Phone: +49 30 80191-0 Fax: +49 30 80191-200 Web: www.knick.de Email: info@knick.de

Stratos Pro A2.. Oxy: Oxygen Measurement



TA-212.145-KNE04 20170831

Software version: 3.x